


Note: Bed collar to cap and bolt on with 4 off M4 machine screws set up from underneath. Attach  $\varnothing 32$  rubber hose to collar with s/s hose clip and lead to top roller fitting (see 077/03/005/03).

JOIN OF BEDDED SECTION OF CAP TO BONDED SECTION & SLOT FOR ROPES TO LEAD OUT OF CASE.  
Scale 1/2

**General Notes:**

1. The Zero Point is the intersection of the Datum Water Line (dwl) with the stemface.
2. Positions are measured fwd and aft (marked "-") of the Zero Point.
3. Heights are measured above and below (marked "-") the dwl.
4. Offsets are measured each side of the fore-&-aft centreline.
5. Waterlines are designated "wl" followed by their height.
6. Buttocks are designated "b" followed by their offset.
7. Diagonals are designated "d" followed by their start height on the centreline and their angle to it.
8. Offsets on diagonals are measured down the angle of the diagonal.
9. Offsets are to inside of skin unless noted otherwise.

 <b>Whisstock</b> boats and boat plans	support@whisstock.com	
	<b>Boat 077</b> <b>Centrecase Sides</b>	
Scale	1/5 & 1/2	
Date	20/05/2000	
Plan No.	077/005/03	
Issue No.	01 web	
All dimensions in millimetres unless noted otherwise		
<small>© bmarkweb Ltd 2002 All Rights Reserved</small>		